


Sullivan Classrooms – 105 courtroom

All Sullivan Hall classrooms come equipped with standardized technology interfaces.



To route a device to the projector, Press the **“Projector”** button next to it. (This also **turns on projector**, lowers screen, and adjusts lights.)

To preview the device on podium LCD, press **“Monitor”**. This does not route anything to the projector.

Press **HELP** for emergencies.

This can be used to call Campus Security by phone.

The control panel interface includes the following elements:

- Buttons for **Laptop**, **Projector**, and **Monitor**.
- Buttons for **Doc Cam**, **Projector**, and **Monitor**.
- Buttons for **DVD**, **Projector**, and **Monitor**.
- Buttons for **VCR**, **Projector**, and **Monitor**.
- Buttons for **Jury Room** and **Projector**.
- Buttons for **Logo** and **Projector**.
- Buttons for **Blank** and **Projector**.
- Buttons for **Projector**, **Lights**, **Mic Volume**, **Screen**, **Admin**, and **Telephone**.
- Volume controls for **Media** (VHS/DVD) and **Shure Wireless** (clip-on).
- DVD Control** section with buttons for **Play**, **Stop**, **Next**, **Previous**, **Menu**, **Enter**, **Return**, and **Disc Open**.
- Help** and **System Off** buttons.

Press **“System Off”** when you leave. This shuts down everything.

Volume Controls:
Media = VHS/DVD and Laptop
Wireless = clip-on

Routes Jury Room Camera to Projector

Use **Logo** to Route SU log on screen.
 Use **Blank** to stop projecting, but leave projector on.

Device controls will appear in this window.

Document Reader Controls:

- AF** = Autofocus
- Rotate** = rotates 90°
- Brightness** = Adjust contrast
- Lamp** = turns light on/off